



**EVOTECH**®  
P E R F O R M A N C E


Kawasaki Z1000 SX  
Crash Protection


Installation Instructions





## Kit Contents PRN014246


- |                                   |                                   |
|-----------------------------------|-----------------------------------|
| (A) 1 x L/H Bracket               | (H) 1 x M12 x 70 x 1.25mm Caphead |
| (B) 1 x R/H Bracket               | (I) 1 x M10 x 95 x 1.25mm Caphead |
| (C) 1 x R/H Bobbin Spacer         | (J) 2 x M10 x 85 x 1.25mm Caphead |
| (D) 1 x R/H Rear Spacer           | (K) 2 x M12 x 85 x 1.25mm Caphead |
| (E) 1 x L/H Bobbin Spacer         | (L) 2 x M12 Washer                |
| (F) 1 x L/H Rear Spacer           | (M) 2 x Polyurathane Washer       |
| (G) 1 x M10 x 60 x 1.25mm Caphead | (N) 2 x Bobbin Heads              |













Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides



Repeat  
Both Sides



Repeat  
Both Sides



Repeat  
Both Sides

**RELEASE**  
 A red arrow pointing right with three vertical bars to its left, followed by a screwdriver icon.

**RE-SET**  
 A red arrow pointing left with three vertical bars to its left, followed by a screwdriver icon.

**RE-FIT**  
 A red arrow pointing right with three vertical bars to its left, followed by a screwdriver icon.



Repeat  
Both Sides

RELEASE




RE-SET




RE-FIT







Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides






Repeat  
Both Sides






Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides




Repeat  
Both Sides





Repeat  
Both Sides




Repeat  
Both Sides











J


G


 Fully Tighten  
45Nm

The complex block contains a green-bordered rectangle. On the left is a red triangle with a white exclamation mark inside, with the word 'Caution' written below it. To the right of the symbol, the text 'Fully Tighten' is written in a bold, sans-serif font, and '45Nm' is written below it in a slightly smaller font.











 Fully Tighten  
45Nm





Reverse Stages

28 - 1











 **ESSENTIAL CHECKS** 

It is recommended that periodic inspections are made to ensure that all bolts are tightened to the specified torque settings.

Should the bike be involved in an accident a thorough inspection should be made and any components that have taken an impact, no matter how small, be replaced



**EVOTECH**<sup>®</sup>  
P E R F O R M A N C E

[www.evotech-performance.com](http://www.evotech-performance.com)